


RonBox SPINDLE REPLACEMENT

Applies to RonBox 1 and 2 with vertically operating toggle switch(es)

Look through the hole in the end of the housing at the switch body and you will see an arrow head on one arm of the cross slot as shown below.



Align the spindle so the arrow on the end of it is pointing in exactly the opposite direction to the arrow on the switch body and then insert it into the slot. It will click home if given a slight wiggle as it is pressed in. Use only gentle pressure.

Alternatively if you've lost the spindle, just reverse the settings on the label eg with switch pointing to 1 as shown on the label, (3 o'clock) the actual switch settings in use is 6.